


# How to Navigate the NVR or DVR Main Menu

- For this process you will need a monitor and a mouse connected directly to the NVR or DVR.
- Click anywhere on the screen to login to the DVR main menu
- DVR will auto-lock itself after 5 min when left alone



Login

User Name

Password


DVR is locked. Please input username and password.

OK Cancel

# How to Navigate the NVR or DVR Main Menu

## Quick Menu

- Right clicking anywhere within the live view images will bring up the “Quick Menu” giving access to all the setup and features of the NVR or DVR.
- Select Menu to access the NVR or DVR settings



# How to Navigate the NVR or DVR Main Menu

- The Main Menu is the primary interface with the NVR or DVR system.


- Lock [1]

NVR or DVR will require user to login to preform any action.




- Logout [2]

NVR or DVR will bring up the Login window.



- Live View [3]

NVR or DVR will return to the cameras live video screen.






# How to Navigate the NVR or DVR Main Menu

- Each menu is laid out the same way.

- Submenus [4] are shown down the left.
- Each submenu will have tabs [5] across the top.



# How to Navigate the NVR or DVR Main Menu

- Don't forget to click Apply. The Settings will be lost!



- Right-clicking anywhere on the screen will bring you back to the previous menu or exit to the live view.

